# DIVISION 26 - ELECTRICAL SECTION 26 05 26 - GROUNDING AND BONDING FOR ELECTRICAL SYSTEMS

# PART 1 - GENERAL

### 1.01 SUMMARY

- A. Section Includes:
  - 1. Methods and materials for grounding systems and equipment.

## 1.02 SUBMITTALS

- A. Submit in accordance with requirements of Section 01 33 00.
- B. Product Data: For each type of product indicated.
- C. Plans showing dimensioned as-built locations of grounding features specified in Part 3 "Field Quality Control" Article, including the following:
  - 1. Ground rods.
  - 2. Bonding to water pipes.
  - 3. Bonding to foundation reinforcing steel.
- D. Field quality-control test reports.

### 1.03 QUALITY ASSURANCE

- A. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70 by a qualified testing agency and marked for intended use.
- B. Comply with UL 467 for grounding and bonding materials and equipment.

# PART 2 - PRODUCTS

### 2.01 CONDUCTORS

- A. Insulated Conductors: Copper or tinned-copper wire or cable insulated for 600 V unless otherwise required by applicable Code or authorities having jurisdiction.
- B. Bare Copper Conductors:
  - 1. Solid Conductors: ASTM B 3.
  - 2. Stranded Conductors: ASTM B 8.
  - 3. Tinned Conductors: ASTM B 33.

# 2.02 CONNECTORS

- A. Listed and labeled by a nationally recognized testing laboratory acceptable to authorities having jurisdiction for applications in which used, and for specific types, sizes, and combinations of conductors and other items connected.
- B. Bolted Connectors for Conductors and Pipes: Copper or copper alloy, bolted pressure-type, with at least two bolts.
  - 1. Pipe Connectors: Clamp type, sized for pipe.
- C. Welded Connectors: Exothermic-welding kits of types recommended by kit manufacturer for materials being joined and installation conditions.

#### 2.03 GROUNDING ELECTRODES

A. Ground Rods: Copper-clad steel; 3/4 inch by10 feet.

# PART 3 - EXECUTION

#### 3.01 APPLICATIONS

- A. Conductors: Install solid conductor for No. 8 AWG and smaller, and stranded conductors for No. 6 AWG and larger, unless otherwise indicated.
- B. Underground Grounding Conductors: Install bare copper conductor, No. 2/0 AWG minimum.
  - 1. Bury at least 24 inches below grade.
- C. Conductor Terminations and Connections:
  - 1. Pipe and Equipment Grounding Conductor Terminations: Bolted connectors.
  - 2. Underground Connections: Welded connectors.
  - 3. Connections to Structural Steel: Welded connectors.
  - 4. Connection to Foundation Reinforcing Steel: Welded connectors.

### 3.02 EQUIPMENT GROUNDING

- A. Install insulated equipment grounding conductors with all feeders and branch circuits.
- B. Signal and Communication Equipment: For alarm, and other communication equipment, provide No. 4 AWG minimum insulated grounding conductor in raceway from grounding electrode system to each service location, terminal cabinet, wiring closet, and central equipment location.

C. Poles Supporting Outdoor Lighting Fixtures: Install grounding electrode and a separate insulated equipment grounding conductor in addition to grounding conductor installed with branch-circuit conductors.

# 3.03 INSTALLATION

- A. Grounding Conductors: Route along shortest and straightest paths possible, unless otherwise indicated or required by Code. Avoid obstructing access or placing conductors where they may be subjected to strain, impact, or damage.
- B. Ground Rods: Drive rods until tops are 2 inches below finished floor or final grade, unless otherwise indicated.
  - 1. Interconnect ground rods with grounding electrode conductor below grade and as otherwise indicated. Make connections without exposing steel or damaging coating, if any.
  - 2. For grounding electrode system, install a sufficient number of ground rods to obtain desired ground resistance, spaced at least one-rod length from each other and located at least the same distance from other grounding electrodes, and connect to the service grounding electrode conductor.
    - a. At service entrance, provide a minimum of three ground rods buried in ground roughly 10 feet apart from each other forming an triangle and connecting them with copper conductors.
- C. Bonding to Concrete Foundation Reinforcing Steel: Use exothermic-welded connectors to bond to 20 ft or more of 1/2 in. foundation and/or footing reinforcing steel at each buildings and structure. Where 20 ft of reinforcing steel is not available, imbed 20 ft or more of bare copper not smaller than 4 AWG.
- D. Bonding Straps and Jumpers: Install in locations accessible for inspection and maintenance, except where routed through short lengths of conduit.
  - 1. Bonding to Structure: Bond straps directly to basic structure, taking care not to penetrate any adjacent parts.
  - 2. Bonding to Equipment Mounted on Vibration Isolation Hangers and Supports: Install so vibration is not transmitted to rigidly mounted equipment.
  - 3. Use exothermic-welded connectors for outdoor locations, but if a disconnect-type connection is required, use a bolted clamp.
- E. Grounding and Bonding for Piping:
  - 1. Install insulated copper grounding conductors, in conduit, from building's main service equipment or electrical grounding bus to metal piping entrances to building. Connect grounding conductors to metal water pipes using a bolted clamp connector or by bolting a lug-type connector to a pipe flange, using one of the lug bolts of the flange. Bond metal grounding conductor conduit or sleeve to conductor at each end.

- 2. Use braided-type bonding jumpers to electrically bypass water meters. Connect to pipe with a bolted connector.
- 3. Bond each above-ground portion of gas piping system downstream from equipment shutoff valve.

# 3.04 FIELD QUALITY CONTROL

- A. Perform the following tests and inspections and prepare test reports:
  - 1. After installing grounding system but before permanent electrical circuits have been energized, test for compliance with requirements.
  - 2. Test completed grounding system at each location where a maximum ground-resistance level is specified, at service disconnect enclosure grounding terminal, and at individual ground rods. Make tests at ground rods before any conductors are connected.
    - a. Measure ground resistance not less than two full days after last trace of precipitation and without soil being moistened by any means other than natural drainage or seepage and without chemical treatment or other artificial means of reducing natural ground resistance.
    - b. Perform tests by fall-of-potential method according to IEEE 81.
  - 3. Prepare dimensioned drawings locating each ground rod and ground rod assembly, and other grounding electrodes. Identify each by letter in alphabetical order, and key to the record of tests and observations. Include the number of rods driven and their depth at each location, and include observations of weather and other phenomena that may affect test results. Describe measures taken to improve test results.
- B. Report measured ground resistances that exceed 10 ohms and include recommendations to reduce ground resistance.

# **END OF SECTION**